



Quick Installation Guide


Outdoor HD Wireless IP Camera



Model:SABIP1200

V1.0

Package Contents



IP Camera




Power Adapter



Mounting Bracket



Ethernet Cable



Resource CD




Quick Installation Guide




Wi-Fi Antenna

1 Hardware Introduction

Physical Description



Hardware Installation




1. Screw the mount on the wall with the 3 screws provided.
2. Install the camera on the mounting bracket with 1 screw to complete installation.

Please Note:

The tail line's wall hole must be lower than socket, ensure that the rain will not wet out device through tail line.

■ Hardware Connection



1. Install wireless antenna and position upright.
2. Connect the power adapter to the camera.
3. Turn on your wireless router.

Before you start, please note:

- Make sure your smartphone is connected to your wireless router and located near the IP Camera.
- Do not use an ethernet cable to connect the camera if you want to use a wireless connection.

2 Add the IP Camera

You can add the IP Camera by Smart Phone.

1. Download the App

You can go to the App Store or Google Play store and search for **"SAB IPC Viewer"**. please download and install it.

The App icon will be displayed after successful installation:



SAB IPC Viewer

2. Add the IP Camera

Run the APP, then you can tap the "+" button on the App and follow the wizard to add your camera.

3 Access the IP Camera

After your camera has been successfully added, you can access the IP Camera via the App or computer.

Please Note:

If you want to use your camera in traditional way, you can search and access its local website in LAN(Local Area Network).

Please copy the "IP Camera Search Tool" file from the CD to your computer, run it to search and access the IP Camera in LAN.



4 FAQ

Forget Username / Password

Restore camera back to factory settings:

1. Press "Reset" button for about 10 seconds with camera powered on.
2. Release the button and wait about 30 seconds, the camera will automatically restart, and restore factory settings with its username / password recovery to admin / (blank) .

Please Note:

- After restore to factory default settings, you need to config the Wi-Fi connection again, you can follow the Setup Wizard of the App to add again.
- In case your device failed to add by Wi-Fi, you can use WPS or wired connection. please refer to the User Manual on the CD.

